

Giant 'Q' Mobile — 18 Pendants

Mobile « Q » Géant — 18 Suspensions

REF. M09QLS999 · FOR PROFESSIONAL INSTALLER USE ONLY

**Mains connection must be carried out by a qualified electrician.**

Disconnect power at the circuit breaker before any wiring work. Do not exceed 11 W per E27 socket. Height is pre-set at the factory — do not attempt to adjust cable lengths on site without disconnecting all wiring at the ceiling rose.

ELECTRICAL SPECIFICATIONS

Sockets	18 x E27
Max. per socket	11 W filament LED
Total load	198 W
Current draw	0.86 A @ 230 V
Supply voltage	230 V AC / 50 Hz
Wiring method	Wago connectors
Connections	Line + Neutral (2 slots)
Circuit breaker	16 A minimum recommended

MECHANICAL SPECIFICATIONS

Fixture weight	8 – 10 kg
Ceiling hook load	Min. 15 kg rated
Canopy diameter	20 cm
Fixing screws	3 x 80 x 6 mm (supplied)
Wall plugs	Plastic, for brick (supplied)
Installation ht.	Pre-set by Po! Paris
Min. height	75 – 100 cm
Cable finish	Natural linen or Black textile

INSTALLATION PROCEDURE

- 1 Switch Off Power**

Turn off the lighting circuit at the mains circuit breaker before starting any work.
- 2 Fix the Ceiling Hook**

Install a single ceiling hook rated for a minimum of 15 kg. Ensure it is anchored into a structural joist or solid masonry.
- 3 Hang the Fixture**

Suspend the assembled mobile from the ceiling hook. The height has been pre-set by Po! Paris to the customer's specification — do not adjust on site without first disconnecting all wiring at the ceiling rose. Follow the assembly instructions available on our website. Do not attempt assembling the structure and shades before hanging the lamp to the ceiling.
- 4 Wire the Ceiling Rose**

Connect Line (L) and Neutral (N) from the mains supply into the two designated Wago connector slots inside the ceiling rose. Total load: 198 W / 0.86 A at 230 V.
- 5 Mount the Ceiling Rose**

Attach the ceiling rose (canopy, 20 cm diameter) using the 3 supplied 80 x 6 mm screws and plastic wall plugs. Ensure the rose sits flush and stable.

6 Fit the Bulbs

Install up to 18 x E27 filament LED bulbs, maximum 11 W each. Do not exceed the rated wattage per socket.

7 Restore Power & Test

Restore power at the circuit breaker and verify all 18 pendants illuminate. Confirm the ceiling rose cover is fully closed and the hook is secure.

Assembly instructions for the shade structure are provided in a separate document supplied with the fixture. Please read before unpacking. For technical questions: paris@po-paris.com | +33 1 42 05 80 08

po-paris.com

paris@po-paris.com

+33 1 42 05 80 08

© 2026 Po! Paris — For installer
use only